


Instrument Panel Fuse Box (1993 Ford Ranger)

troubleshootmyvehicle.com/ford/2.3L/instrument-panel-fusebox



1993 2.3L, 3.0L, 4.0L Ford Ranger Fuse Box

Fuse #	Amp	Fuse Name/Description
1	15 Amp	<ul style="list-style-type: none"> • Headlight Switch. • Radio. • Courtesy Light Switch. • Map Light. • Power Mirror Switch.
2	30 Amp	CIRCUIT BREAKER <ul style="list-style-type: none"> • Wiper/Washer Switch.
3	-	NOT USED
4	15 Amp	<ul style="list-style-type: none"> • Hazard Flasher.

Instrument Panel Fuse Box (1993 Ford Ranger)

troubleshootmyvehicle.com/ford/2.3L/instrument-panel-fusebox

Fuse #	Amp	Fuse Name/Description
5	30 Amp	<ul style="list-style-type: none"> • Turn Signal Flasher.
6	20 Amp	<ul style="list-style-type: none"> • Cruise Control Module.
7	15 Amp	<ul style="list-style-type: none"> • Auto Day/Night Mirror. • Instrument Cluster. • Low Oil Level Relay. • Warning Chime Module. • Electronic Shift Control Switch.
8	15 Amp	<ul style="list-style-type: none"> • Horn Switch (w/o Cruise Control). • Horn Relay (w/ Cruise Control).
9	30 Amp	<ul style="list-style-type: none"> • Blower Motor.
10	15 Amp	<ul style="list-style-type: none"> • Stop Light Switch. • Headlight Switch.
11	15 Amp	<ul style="list-style-type: none"> • Radio. • Headlight Switch.
12	20 Amp	<p>CIRCUIT BREAKER</p> <ul style="list-style-type: none"> • Flash-to-Pass Switch (Beam Select Switch). • Power Lumbar Support Switch.
13	10 Amp	<ul style="list-style-type: none"> • Instrument Illumination. • Fog Light Illumination. • Radio Illumination. • Overhead Console Illumination. • Electronic Shift Control Switch. • Ashtray Illumination. • Heater-A/C Control Switch.
14	30 Amp	<p>CIRCUIT BREAKER</p> <ul style="list-style-type: none"> • Master Window Control Switch.
15	20 Amp	<ul style="list-style-type: none"> • Rear ABS Module.
16	20 Amp	<ul style="list-style-type: none"> • Radio Amp.
17	10 Amp	<ul style="list-style-type: none"> • A/C-Heater Control Assembly.
18	15 Amp	<ul style="list-style-type: none"> • Heated Oxygen Sensor.